



Jamestown University Chapel
[Click here to see more...](#)

NRC AND ABSORPTION COEFFICIENTS

The Noise Reduction Coefficient (NRC) and Absorption Coefficients are widely used metrics that indicate how effectively a material absorbs sound.

These metrics help designers and engineers create balanced, comfortable environments by predicting how finishes and treatments influence a room's acoustic character. Like RT60 guides reverberation control



Understanding NRC...

01. What is NRC?


02. What are Absorption Coefficients?

03. Material Selection & Real-World Applications.

What is NRC and why it matters...

NRC is a simple 0.00 – 1.00+ rating of how much noise energy a material absorbs. From reflective surfaces like concrete (0.00) to highly absorptive options like acoustic foam (1.00), an NRC value is a quick way to gauge how a surface can be implemented to improve speech clarity and reduce reverberation noise. While simplified, it can offer insight into acoustic performance. Ideal NRC levels vary by space and design goals.

NRC Ratings of some materials






Absorption Coefficient

An absorption coefficient describes how much sound a material absorbs at a specific frequency, on a scale from 0.00 (fully reflective) to 1.00 (highly absorptive). Measured in octave or 1/3-octave bands, it shows how a surface behaves across all frequencies. This offers more detail in the event a certain frequency band needs addressing.

Absorption Coefficients of some materials



NRC vs Absorption Coefficients

While NRC provides a simplified summary and is focused primarily on 4 frequencies (250 Hz, 500 Hz, 1000 Hz, and 2000 Hz) Absorption Coefficients show performance within individual octave bands. This is critical because two materials can share the same NRC while behaving very differently across frequencies.

Material Selection

Selecting the right absorption materials requires balancing aesthetics, performance, and available mounting locations. In many rooms, the ceiling offers the greatest continuous surface area, but relying on ceilings alone often leaves vertical reflection paths untreated.

A well-designed space may combine:

- Ceiling clouds or baffles
- Fabric-wrapped wall panels
- Perforated gypsum systems
- Mineral fiber or wood slat treatments
- Specialty products with broadband absorption

Real-World Application

Once materials are selected, the next step is understanding how they will behave in the actual space. Instead of relying solely on post-construction modeling, NRC and Absorption Coefficient driven design emphasizes upfront validation, which involves reviewing manufacturer data, assessing mounting conditions, and confirming that materials will perform as rated once installed. Field observations, such as identifying dominant reflection paths, reverberant “hot spots,” or areas with insufficient absorption, guide the placement of treatments to achieve the most significant impact. This approach ensures that the final design isn’t just theoretically correct but is strategically deployed to solve real-world acoustic challenges, delivering measurable improvements in clarity, comfort, and noise control.



Jamestown University
[Click here to see more...](#)

IN CLOSING...

Great acoustics aren't accidental; they come from intentional design, informed material choices, and a clear understanding of how spaces actually behave. NRC and Absorption Coefficients provide quick insight into what material may be best for the job.

As more projects adopt data-driven design, metrics such as NRC and Absorption Coefficients help align materials with performance expectations early on. This ensures treatments meaningfully support the space's purpose, whether it's a classroom, restaurant, studio, fitness center, or open office. By reviewing the NRC values and Absorption Coefficients of a material, designers and installers can proactively address noise issues rather than reacting after construction. The result is a space that looks polished and sounds balanced, clear, and comfortable.

To create spaces that offer clarity...

**NRC values and Absorption Coefficients
are invaluable tools**